




Levolan 60



146384-02

GEZE

2 mm
4 mm
4 mm
4 mm
13 mm








EN 1527
EN 1670
FH : FB ≤ 3:1
60 kg

			FB [mm]
Levolan 60 SoftStop			≥570
Levolan 60 SoftStopDuo			≥770



=
ESG
EN 12150-1
TEMPERED

=
VSG/LSG
EN ISO
12543-1


2

i**i+****A****i+****B****i+****C****i+****D****i+****E****i+****F****G****12**

i




1/10




1




$$LL = 2 * FB - 30 + 4$$








LL		Y
1650	5x	125
2050	6x	150
2450	7x	175
6000	18x	25



2




ESG
EN 12150-1
TEMPERED




2x3 mm
ESG 8 mm

2x2 mm
ESG 10 mm

2x1 mm
ESG 12 mm




VSG/LSG
EN ISO
12543-1



1x
1x 3 mm
VSG 8,76 mm

1x
1x 2 mm
VSG 10,76 mm




ID 133034


3



4 mm




4 mm



4



4 mm




ESG
EN 12150-1
TEMPERED

T [mm]

≥440

636

4/10




1



2


2



3


≥15 mm

5 Nm




5

5/10











6






7

6/10

 $\varnothing 9,5-12 \text{ mm}$  $\varnothing 4,5-6,0 \text{ mm}$ 




EN 572-2
EN 572-5




9


8/10



10




4 mm




2 Nm





11



9/10



4 mm 13 mm








>30°






12




10/10




13




A




A-1/2




i+ 7








i+ 12




i+ 13









A diagram of a square with dimension lines. A horizontal double-headed arrow above the square indicates its width, and a vertical double-headed arrow to the right of the square indicates its height.







i+11








C






C-1/2




i+ 7













i+ 13

















D





D-1/2







E**E-1/2****i+ 7****1**



3




2




5







i+ 12



click






A diagram of a square with a thick black border. Above the square, a horizontal double-headed arrow indicates the width. To the right of the square, a vertical double-headed arrow indicates the height.




i+ 4






Ø 7-8 mm
≤ Ø 4 mm





F-2/2








i+ 7





i+ 11



G



1




2



4 mm



5 Nm





3



4 mm



1



2 Nm



4



Germany

GEZE Sonderkonstruktionen GmbH
Planken 1
97944 Boxberg-Schweigern
Tel. +49 (0) 7930 9294 0
Fax +49 (0) 7930 9294 10
E-Mail: sk.de@geze.com
GEZE GmbH
Niederlassung Süd-West
Tel. +49 (0) 7152 203 594
E-Mail: leonberg.de@geze.com
GEZE GmbH
Niederlassung Süd-Ost
Tel. +49 (0) 7152 203 6440
E-Mail: muenchen.de@geze.com
GEZE GmbH
Niederlassung Ost
Tel. +49 (0) 7152 203 6840
E-Mail: berlin.de@geze.com
GEZE GmbH
Niederlassung Mitte/Luxemburg
Tel. +49 (0) 7152 203 6888
E-Mail: frankfurt.de@geze.com
GEZE GmbH
Niederlassung West
Tel. +49 (0) 7152 203 6770
E-Mail: duesseldorf.de@geze.com
GEZE GmbH
Niederlassung Nord
Tel. +49 (0) 7152 203 6600
E-Mail: hamburg.de@geze.com
GEZE Service GmbH
Tel. +49 (0) 1802 923392
E-Mail: service-info.de@geze.com

Austria

GEZE Austria
E-Mail: austria.at@geze.com
www.geze.at

Baltic States

GEZE GmbH Baltic States office
E-Mail: office-latvia@geze.com
www.geze.com

Benelux

GEZE Benelux B.V.
E-Mail: benelux.nl@geze.com
www.geze.be
www.geze.nl

Bulgaria

GEZE Bulgaria - Trade
E-Mail: office-bulgaria@geze.com
www.geze.bg

China

GEZE Industries (Tianjin) Co., Ltd.
E-Mail: chinasales@geze.com.cn
www.geze.com.cn

GEZE Industries (Tianjin) Co., Ltd.
Branch Office Shanghai
E-Mail: chinasales@geze.com.cn
www.geze.com.cn

GEZE Industries (Tianjin) Co., Ltd.
Branch Office Guangzhou
E-Mail: chinasales@geze.com.cn
www.geze.com.cn

GEZE Industries (Tianjin) Co., Ltd.
Branch Office Beijing
E-Mail: chinasales@geze.com.cn
www.geze.com.cn

France

GEZE France S.A.R.L.
E-Mail: france.fr@geze.com
www.geze.fr

Hungary

GEZE Hungary Kft.
E-Mail: office-hungary@geze.com
www.geze.hu

Iberia

GEZE Iberia S.R.L.
E-Mail: info@geze.es
www.geze.es

India

GEZE India Private Ltd.
E-Mail: office-india@geze.com
www.geze.in

Italy

GEZE Italia S.r.l.
E-Mail: italia.it@geze.com
www.geze.it

GEZE Engineering Roma S.r.l.
E-Mail: roma@geze.biz
www.geze.it

Poland

GEZE Polska Sp.z o.o.
E-Mail: geze.pl@geze.com
www.geze.pl

Romania

GEZE Romania S.R.L.
E-Mail: office-romania@geze.com
www.geze.ro

Russia

OOO GEZE RUS
E-Mail: office-russia@geze.com
www.geze.ru

Scandinavia – Sweden

GEZE Scandinavia AB
E-Mail: sverige.se@geze.com
www.geze.se

Scandinavia – Norway

GEZE Scandinavia AB avd. Norge
E-Mail: norge.se@geze.com
www.geze.no

Scandinavia – Denmark

GEZE Danmark
E-Mail: danmark.se@geze.com
www.geze.dk

Singapore

GEZE (Asia Pacific) Pte, Ltd.
E-Mail: gezesea@geze.com.sg
www.geze.com

South Africa

GEZE Distributors (Pty) Ltd.
E-Mail: info@gezesa.co.za
www.geze.co.za

Switzerland

GEZE Schweiz AG
E-Mail: schweiz.ch@geze.com
www.geze.ch

Turkey

GEZE Kapi ve Pencere Sistemleri
E-Mail: office-turkey@geze.com
www.geze.com

Ukraine

LLC GEZE Ukraine
E-Mail: office-ukraine@geze.com
www.geze.ua

United Arab Emirates/GCC

GEZE Middle East
E-Mail: gezeme@geze.com
www.geze.ae

United Kingdom

GEZE UK Ltd.
E-Mail: info.uk@geze.com
www.geze.com

GEZE GmbH

Reinhold-Vöster-Straße 21–29
71229 Leonberg
Germany

Tel.: 0049 7152 203 0
Fax: 0049 7152 203 310
www.geze.com

